# 10 Steps for Great Canvas Corners

STEP 1

To begin pull the corner of the canvas towards the centre of the frame.

STEP 2

Pinch the canvas together at the corner. This pinch may need to be adjusted to ensure the lower fold is in line with the corner of the Wunderbars as shown on the next step.

STEP 3

Fold the bottom of the canvas up. You need to make the bottom fold and the corner of the frame line up as straight as possible to create the box corner. If it is not straight then adjust the pinch in step 2.

STEP 4

Pull up the fold, again paying attention that the two folds are as straight as possible to create the corner of the canvas.

STEP 5

Push the newly created fold upwards and down onto the frame.

STEP 6

Flatten the canvas down in preparation to pull the side fold of canvas over. Take this opportunity to check the corner is looking smart

STEP 7

Now, pull over the side fold created. Hold this down with your thumb and check again that you are satisfied with your corner.

STEP 8

Lift the fold back up that you created in step 7 and staple down the flat of the canvas, taking particular care not to staple over the corner join on the Wunderbars or too close to the "Step 7" fold. Stapling over the join will prevent the frame from expanding properly on the stretch

STEP 9

Pull the fold from step 7 back over and staple the other opposite corner, again taking care not to staple over the corner of the Wunderbars.

STEP 10

Finally finish with a staple on the fold to hold it down. Again taking care not to staple over the join.

Wunderbars
Constant tension stretcher bars

See more online at www.wunderbars.com